





Installation manual


Diffusers

PBQ + DNQ




PBQ Installation

- Square plenum box design
- Horizontal duct connection





PBQ dimensions


Model	Ø d	AxB	H		C
			(PBQ-H)	(PBQ-V)	
300	160	290 x 292,5	248	228	40,5
400	200	390 x 392,5	288	228	40,5
500	200	490 x 492,5	288	228	40,5
600	250	590 x 592,5	338	228	40,5
625	250	615 x 617,5	338	228	40,5



1. Install suspension for the plenum box



2. Check the air flow cable position








DNQ diffuser installation

- Fix the diffuser with central screw included with the product


3. Install diffuser with central crew




Installation in continuous ceilings



Installation into grid ceilings



Installation in T-bar ceilings, diffuser face rests on T-bars



Installation in T-bar ceilings



AIR DISTRIBUTION

Projektiranje, proizvodnja i održavanje opreme za klimatizaciju, ventilaciju i čiste prostore.
Design, production and service of Ventilation, Air-Conditioning and Cleanroom equipment.

📍 Gradna 78A, 10430 Samobor, Croatia
☎ +385 (0)1 33 62 513
✉ info@klimaoprema.hr
🌐 www.klimaoprema.hr